



### Injector Connector Tube

Permits application of combined discharge of two or more Series SL-V, SL-1, SL-41 or SL-44 injectors through one feed line. Used where bearing size is such that multiple injector output is required. Fittings 1/8" NPT male each end. Carbon steel construction.

Model	For Injector Series	Connections
81646	SL-V, SL1, SL41, SL44	1/8" NPTF Male



### Injector Outlet Adapter

Converts individual injector lubricant outlet when standard 1/8" O.D. tube is not desired. All adapters are carbon steel unless otherwise noted.

Model	For Injector Series	Outlet Connections
14988	SL32, SL33, SL42, SL43	1/8" NPTF Female
84200		1/4" O.D. Tube
14991		1/8" NPTF Male
249281		4 mm Tube
249282		6 mm Tube

### Manual Grease Fitting Adapter

Allows manual lubrication of the machine between normal system cycles. Carbon steel with Nitrile seals.

Model	For Injector Series	Outlet Connections
84195	SL32, SL33, SL42, SL43	1/8" O.D. Tube
84203		1/4" O.D. Tube



### Injector Locking Cap

Carbon steel locking caps set injectors to fixed output.

Model	For Injector Series	Fixed Volume Output
102781	SL32, SL43	.002 in <sup>3</sup> / .033 cc
	SL33, SL42	.003 in <sup>3</sup> / .049 cc



### Injector Cover Caps

Injector cover caps are designed to protect the injector from dirt, harmful liquids and fumes.

Model	Fits Injector Series	Covers	Material	Length		Diameter	
				in	mm	in	mm
273088	SL-V	Indicator Stem	Polycarbonate	1.5	38.1	.715(ID)	18.2
273089	SL-V XL			2.2	55.9	.715(ID)	18.2
83272	SL1, SL44		Vinyl	1.5	38.1	.69(ID)	17.5
83730	SL11			2.0	50.8	1.125(ID)	28.6
68483	SL32, SL33, SL42, SL43	Measuring Chamber	Aluminum	1.25	31.2	.5(ID)	12.7
90537	SL1, SL41, SL44	Injector Body		3.25	82.6	1.19(ID)	30.2

